



**Montagematerial / Mounting Material**

Nr./No.	Artikel / Article	Dim.	#
1	Sechskant-Schraube / Hexagonal screw	M 10 x 110	2
2	Sechskant-Schraube / Hexagonal screw	M 10 x 100	4
4	Sechskant-Schraube / Hexagonal screw	M 8 x 55	5
5	Sechskant-Schraube / Hexagonal screw	M 8 x 40	4
6	Sechskant-Schraube / Hexagonal screw	M 8 x 30	4
7	Sechskant-Schraube / Hexagonal screw	M 10 x 60	1
8	Ringkopf-Mutter / Ring-headed nut	M 10	1
9	Stop Mutter / Lock nut	M 10	6
10	Stop Mutter / Lock nut	M 8	13
13	Beilagscheibe / Flat washer	M 10 x 30	13
14	Beilagscheibe / Flat washer	M 8 x 20	12
15	Beilagscheibe / Flat washer	M10 x 20	4
16	Niro Hülse / Stainless steel bush	80 x 15/2	2
17	Abstandhalter/Spacer for shock absorber	17 x 19/4	2
18	Abstandhalter/Spacer for shock absorber	22 x 19/2	2

*Bereits montiert / Already mounted*

19	Abdeckung / Plug connection	40 x 20	2
20	Abdeckung / Plug connection	50 x 50	2



**RETTUNGSANHÄNGER  
RESCUE TRAILER**

MG / 13.11.2024      Version: 8.0

**93152 / 93157 / 93166**

Montageanleitung - Kufen für Anhänger  
*Mounting Instruction - Runners for Trailer*