



Montagematerial / Mounting Material

Nr./ No.	Artikel / Article	Dim.	#
1	Sechskant-Schraube / Hexagonal screw	M 10 x 60	1
2	Sechskant-Schraube / Hexagonal screw	M 8 x 55	1
3	Sechskant-Schraube / Hexagonal screw	M 8 x 40	4
5	Ringkopf-Mutter / Ring-headed screw nut	M 10	1
6	Stop Mutter / Lock nut	M 8	5
7	Beilagscheibe / Flat washer	M 8 x 20	8
8	Beilagscheibe / Flat washer	M 10 x 30	1
10	Sechskant-Schraube / Hexagonal screw	M 16 x 30	2
11	Beilagscheibe / Flat washer	M 16 x 50	2
12	Rad-Schraube / Wheel screw	M 12 x 25	16

Bereits montiert / Already mounted

9	Abdeckung / Plug connection	40 x 20	2
---	-----------------------------	---------	---

TYROMONT
Alpine Rescue Equipment

RETTUNGSANHÄNGER RESCUE TRAILER

MG / 29.10.2024

Version: 5.0

93158 / 93168 / 93176

Montageanleitung - Räder für Anhänger
Mounting Instruction - Wheels for Trailer