



## Akja 2000 - Short Version



Designed for **2-rescuer** operation in **all kind of snow** - covered terrain, groomed or ungroomed.

The **classic Akja - Rescue Sled** in one-piece version. Time-proofed design and workmanship, thousands of them worldwide running.

Especially good in **steep and/or icy slopes** and moguls.

Due to the **shorter length** this model is very practicable for off-piste rescue operations.

Also sometimes for **transport with a gondola** this shorter version is needed.

**Long lasting durability:** Manufactured completely from high-strength, corrosion-resistant aluminum alloy for many years of reliable, maintenance-free action.

**Stable running characteristics:** Reinforced steel runners with especially hardened fins provide stable running even in very icy conditions.

**Two pairs of poles** (for two rescuers), can be detached easily by bayonett-lockings. The grips of the handles are high enough for tall rescuers.

With integrated stabilization profiles for increased bending strength.

**Bayonett-lockings** are wear-free, 100% icing-safe and easily to handle.

**Carrying grips** on both ends of the sledge for comfortable lifting and carrying of the sled.

**Four fixation belts with aluminum buckles** for safe fixation of the injured; resistant against breaking and icing, can be operated with skiing-gloves.

Art. No.	<b>93059</b>
Dimensions	Length: 2.000 mm Width: 560 mm Length of poles: 1.650 mm
Weight	26,0 kg (incl. poles)
Comments	Short version of Art. 93031