



FIBER ROPE WINCH ACCESSORIES TRANSPORT BAG

TRANSPORT BAG 35 liter (Art. Nr. 93493)

For the comfortable transport and storage of up to 100 m fibre rope.

Manufactured from **impregnated nylon fabric**, belts PES. Roll-closing with nylon - buckles and padded carrying belts for comfortable usage.



TRANSPORT BAG 59 liter (Art. Nr. 93494)

For the comfortable transport and storage of up to 200 m fibre rope.

Manufactured from **impregnated nylon fabric**, belts PES. Roll-closing with nylon - buckles and padded carrying belts for comfortable usage.

Art. No	93493	93494
Dimensions	Volume: 35 L	Volume: 59 L
	Rope length: 100 m	Rope length: 200 m
	High: 600 mm	High: 700 mm
	Depth: 270 mm	Depth: 310 mm
Weight	Total: 0,64 kg	Total: 0,79 kg



FIBER ROPE WINCH ACCESSORIES CARRYING FRAME TYRmove



Carrying frame TYRmove

Comfortable, energy-saving carrying frame for high alpine use.

Easily attach and carry rescue stretcher, divisible akja, vacuum mattress and other things. Bike and drawbar also can be attached on the frame.

Your own backpack with the man's equipment can also be fixed.

The shoulder strap and hip belt of the Kraxe are well padded and serve as protection against pressure points. The V2 carrying system is dimensionally stable and durable.

No shifting of the load while walking - especially important in inaccessible terrain.

The load is fastened using three fixing straps with a stable clamp. Very robust and easy to use system.

Sturdy aluminum frame and comfortable carrying system enable versatile use - load capacity up to 50 kg.

A 25 cm deep arm with stand serves as the loading area.

The stand enables you to **stand securely** - even on uneven terrain. This also offers additional mounting options.

Scope of delivery: one piece of carrying frame TYRmove incl. 3 fixing straps.

Art. No.	93802	
Dimensions	Width:	350 mm
	Length:	780 mm
	Stage space:	250 mm
Weight	Total:	3,4 kg



TYROMONT Alpin Technik GmbH
Bert-Köllensperger-Str. 6 · 6065 Thaur/Austria
T +43 (0) 5223 23 723-0 · office@tyromont.com
www.tyromont.com



FIBER ROPE WINCH ACCESSORIES EDGE PROTECTOR „ZIMBA“



EDGE PROTECTOR „ZIMBA“

Entirely new developed edge protector for fibre ropes.

Three pressure casted aluminum alloy gliding elements with polished surface provide a **perfectly protected and minimized friction**. **5 guiding grooves** hold the rope in line, even at strong side pull.

Run of the rope **over edges up to 180°**. Due to its physical properties, aluminum leads heat away very fast and therefore does not heat up. Even when ropeing down over very long distances, there is **no temperature increase in the rope** or the protectors.

High stability against tipping over due to large bearing-systems and high side walls.



Art. No.	93436	
Dimension	Width:	160 mm
	Length:	350 mm
Weight	Total:	1,5 kg



TYROMONT Alpin Technik GmbH
Bert-Köllensperger-Str. 6 · 6065 Thaur/Austria
T +43 (0) 5223 23 723-0 · office@tyromont.com
www.tyromont.com