

ANTIROTATIONSLEINE ANTI ROTATIN ROPE 75 m



75m Antirotationsleine zur Verhinderung von Rotationsbewegungen.

Bewährtes und zuverlässiges System zur **Verhinderung von Rotationsbewegungen** des Bergesacks bei Windenaktionen.

75m Leichtseil in Signalfarbe, verstaut in einem **Seilsack**. Die Verbindung der Antirotationsleine mit dem Bergesack erfolgt durch einen **Karabiner mit Schnelllösefunktion**.

Karabiner und Leine sind mit einem Kraftbegrenzer zur Limitierung der Zugkraft auf 35kg verbunden.

Proven and reliable system to avoid rotational movement of a rescue bag.

Proven and reliable system to avoid rotational movement of a rescue bag in downwash during a hoist operation. **75 m light-weight control line** signalcoloured, stored in a **rope-bag**. The anti-rotation line is connected with the rescue bag through a **quick-release carabiner** and a **load limiter** which limits the **pulling power to 70 lbs.**



P/N	93284	
Abmessung Dimension	Länge / Length:	75 m
Gewicht Weight		1,07 kg
Kraftbegrenzer Load limiter		35 kg