

KANTENSCHUTZ ZIMBA EDGE PROTECTOR ZIMBA

Minimale Seilreibung durch große Auflagefläche und polierte Oberfläche.

Hohe Kippstabilität durch breite Auflagestege und erhöhte Seitenwangen.

Fünf Seilführungsritzen bieten gute Führung auch bei schrägem Seilzug. Seilumlenkung von 0° - 180° möglich. Aluminium leitet aufgrund seiner physikalischen Eigenschaften Wärme optimal ab - dadurch wird eine **Erwärmung des Seiles** auch unter höchsten Lasten ausgeschlossen.

Der Kantenschutz ist **absolut wartungs- und verschleißfrei**, da er keine bewegten Teile besitzt.



Entirely new developed edge protector for fibre ropes.

Three pressure casted aluminum alloy gliding elements with polished surface provide a **perfectly protected and minimized friction**. **5 guiding grooves** hold the rope in line, even at strong side pull.

Run of the rope **over edges up to 180°**. Due to its physical properties, aluminum leads heat away very fast and therefore does not heat up. Even when ropeing down over very long distances, there is **no temperature increase in the rope** or the protectors.

High stability against tipping over due to large bearing-systems and high side walls.

P/N	93436	
Abmessung <i>Dimension</i>	Länge/ Length:	350 mm
	Breite/ Width:	160 mm
Gewicht <i>Weight</i>	Gesamt/ Total:	1,5 kg
Anmerkungen <i>Comments</i>		